







HLS800/900






INSTALAČNÍ NÁVOD / INSTALLATION INSTRUCTION





1






2






3








4







5



6



7




Ø 2.8mm

x 4









ST3.5x9.5


x 4



8



24 hodin



9